

ASSEMBLY INSTRUCTION


ITEM#:TV-24、 26024

PLEASE READ BEFORE ASSEMBLING!

Tip #1: Make sure you've taken all the pieces and hardware out of its packaging before discarding the box.


Tip #2: Using page 2 and/or page 3 of instruction manual make sure all pieces and hardware are accounted for.

Tip #3: Read manual before assembling, it helps!



PARTS IDENTIFICATION











ITEM#:TV-24、 26024



(1)	1pc	(4)	1pc
(2)	1pc	(5)	1pc
(3)	1pc	(6)	1pc


HARDWARE IDENTIFICATION

ITEM#:TV-24、26024

A		$\phi 15$	4pcs
B		L29	4pcs
C		$\phi 5 \times 40$	4pcs
D			20pcs
E		$\phi 5$	4pcs
F			2pcs
G			2pcs
H		$\phi 4 \times 16$	16pcs
J		$\phi 8 \times 25$	8pcs
K		It's used for stick the stopper to the connecting hole firmly	1pc

ASSEMBLY INSTRUCTION

ITEM#:TV-24、26024




STEP1


PAGE:3 OF 4

ASSEMBLY INSTRUCTION

ITEM#:TV-24、26024



STEP2



STEP3

STEP4

